

MVM V1.5C Quick Start Guide

Rev 0.95


What Is It?

- An open source easy to use low resolution CMOS camera with on-board real-time image processing.
- Requires 5V, 150 mA power source, and interface through UART port.
- Support 160x120 pixels (QQVGA) and 320x240 pixels (QVGA) color image.
- Current image processing algorithm:
 - Edge detection via Sobel kernel.
 - Bright spot detection.
 - Obstacle detection using luminance contrast.
 - Color detection.
- Coming soon:
 - Line following.
 - Optical flow.
 - Neural-network (no guarantee!)


Block Diagram



Schematic 1 – Micro-controller Core




Version 0.95 Dec 2019




Project	Machine Vision 1.5		
Used for			
Schematic Rev. 0.97		Sheet of 2	
Date	Engineer		
16 Aug 2019	FABIAN KUNG		

Rear View (MVM V1.5C)



Front View (MVM V1.5C)





Files

- All relevant files can be obtained from https://github.com/fabiankung/MVM_V1_5C
- Firmware is build using **Atmel Studio 7**.
- PC software is build using **Visual Studio Community 2017** or later.

Observing the Camera Image via Machine Vision Monitor Software

Step 1 – Power Up the MVM

- Here we assume the MVM is connected to HC-05 Bluetooth wireless module or a USB-to-Serial Converter, as shown in the various implementation examples below. Power up the module.




Link to computer via HC-05 Bluetooth Module

Step 2 – Pair Computer to HC-05


- If need to pair the computer to HC-05.
- Then check virtual COM port number on the computer (for instance by going to the Device Manager).

Step 3 – Run the Machine Vision Monitor Software (MV_Monitor.exe)





1: Select the correct COM port

2: Press the 'Open Port' button



3: Press the 'Start' button
(Press multiple times if necessary)



4: Now the MVM will transmit the image data line-by-line to the monitor software


Version 0.95 Dec 2019

Other Information (1 of 2)

Always close the COM port before shutting down the software

Select between various display options. All these are processed in the MVM. (See next slide)

Change reference line color.



Reference lines

Save the current bitmap in display onto hard disk

For debugging purpose (see source codes)

Use these to move the reference lines.

Other Information (2 of 2)

Machine Vision Monitor - Version 1.02

COM4

Open Port

Close Port/Stop

Start

☒ Luminance RGB
☐ Luminance R
☐ Luminance G
☐ Luminance B
☐ Gradient
☐ Hue
☐ Result

☒ Red
☐ Green
☐ Blue
☐ Yellow

Debug Info

Horizontal Reference Line: 60

Vertical Reference Line: 80

1st byte: 0

2nd byte: 0

3rd byte: 79

4th byte: 59

No. of bytes in RX buffer: 110

Debug byte: 70

Current IPA in Interval 1: 3

Current IPA in Interval 2: 3

HL Up

HL Down

Save Raw Image

Machine Vision Monitor - Version 1.02

COM4

Open Port

Close Port/Stop

Start

☐ Luminance RGB
☐ Luminance R
☐ Luminance G
☐ Luminance B
☒ Gradient
☐ Hue
☐ Result

☒ Red
☐ Green
☐ Blue
☐ Yellow

Debug Info

Horizontal Reference Line: 60

Vertical Reference Line: 80

1st byte: 0

2nd byte: 0

3rd byte: 79

4th byte: 59

No. of bytes in RX buffer: 110

Debug byte: 70

Current IPA in Interval 1: 3

Current IPA in Interval 2: 3

HL Up

HL Down

VL Right

VL Left

Save Raw Image

Machine Vision Monitor - Version 1.02

COM4

Open Port

Close Port/Stop

Start

☐ Luminance RGB
☐ Luminance R
☐ Luminance G
☐ Luminance B
☒ Gradient
☐ Hue
☐ Result

☒ Red
☐ Green
☐ Blue
☐ Yellow

Debug Info

Horizontal Reference Line: 60

Vertical Reference Line: 80

1st byte: 0

2nd byte: 0

3rd byte: 79

4th byte: 59

No. of bytes in RX buffer: 110

Debug byte: 70

Current IPA in Interval 1: 3

Current IPA in Interval 2: 3

HL Up

HL Down

VL Right

VL Left

Save Raw Image

Machine Vision Monitor - Version 1.02

COM4

Open Port

Close Port/Stop

Start

☐ Luminance RGB
☐ Luminance R
☐ Luminance G
☐ Luminance B
☒ Hue
☐ Result

☒ Red
☐ Green
☐ Blue
☐ Yellow

Debug Info

Horizontal Reference Line: 60

Vertical Reference Line: 80

1st byte: 0

2nd byte: 0

3rd byte: 79

4th byte: 59

No. of bytes in RX buffer: 110

Debug byte: 70

Current IPA in Interval 1: 3

Current IPA in Interval 2: 3

HL Up

HL Down

VL Right

VL Left

Save Raw Image


Version 0.95 Dec 2019

14

Connection to External Controller for Robotic Projects

Connection to External Controllers

- Here we use an Arduino Uno to demonstrate the connection.



UART1 Communication Protocol

Image Processing Algorithm (IPA)	To Activate	MVM Output
Search for brightest spot in a scene. Image resolution = 160x120	Send hex values to MVM: 0x10 to search for brightest spot	4 bytes: Byte 1 = 1 (Algorithm ID) Byte 2 = Maximum luminance value (1 to 127). Byte 3 = x coordinate of region Byte 4 = y coordinate of region
Obstacle detection on lower half of the image. Image resolution = 160x120	Send hex value to MVM: 0x20	4 bytes: Byte 1 = 2 Byte 2 = 0b00000b ₂ b ₁ b ₀ Byte 3 = 0b00000b ₂ b ₁ b ₀ Byte 4 = 0b00000b ₂ b ₁ b ₀
Color object detection. Image resolution = 160x120	Send hex values to MVM: 0x30 for yellow-green object 0x31 for red object 0x32 for green object 0x33 for blue object	4 bytes: Byte 1 = 3 Byte 2 = Number of pixels matched Byte 3 = x coordinate of region Byte 4 = y coordinate of region

Example 1 – Activate Search for Brightest Spot Algorithm

- Assume the MVM is connected to an Arduino Uno. The left panel shows a simple Arduino Sketch to activate the image processing algorithm to search for brightest spot on both **Interval 1** and **2**, giving effective response time of 50 ms.

Note:
See Appendix for
Another version
of this code using
SoftwareSerial

```
Example1 | Arduino 1.8.9
File Edit Sketch Tools Help

Example1 $


void setup() {
  // put your setup code here, to run once:
  Serial.begin(57600);
  delay(500); // A 500 ms delay for the module to initialize properly.
  Serial.write(0x10); // Run IPA (image processing algorithm) 1 on interval 1.
  Serial.write(0x10); // Run IPA 1 on interval 2.
}

void loop() {
  // put your main code here, to run repeatedly:

  int nID;
  int nLuminance;
  int nX;
  int nY;


  if (Serial.available() > 3) // Make sure at least 4 bytes in the received buffer
  {
    nID = Serial.read();
    if (nID == 1) // Make sure the data is from IPA 1.
    {
      nLuminance = Serial.read();
      nX = Serial.read();
      nY = Serial.read();

      //
      // Place user routines here
      //
    }
    else
    {
      Serial.flush(); // Flush received buffer.
    }
  }
}
```



Example 1 - More on 'Interval'


- The firmware of MVM V1.5C assigns odd image frames to *Interval 1* and even image frames to *Interval 2*.
- An image processing algorithm (IPA) can be attached to each interval as shown below and executed after acquisition of a new image frame.



- The C code snippet attaches IPA 1 to both Interval 1 and Interval 2 of the execution flow, thus in this setting IPA 1 runs every 50 ms and any changes in scene is detected within 50 ms.

Example 2 - Activate Both Search for Brightest Region (IPA 1) and Obstacle (IPA 2) Algorithms

- In this example we attach IPA 1 to Interval 1 and IPA 2 to Interval 2.
- Thus a robot using the MVM V1.5C can be programmed to move towards a bright light source while at the same time avoid any obstacle on the floor.



```
Example2 | Arduino 1.8.9
File Edit Sketch Tools Help

Example2

void setup() {
  // put your setup code here, to run once:
  Serial.begin(57600);
  delay(500); // A 500 ms delay for the module to initialize properly.
  Serial.write(0x10); // Run IPA (image processing algorithm) 1 on interval 1.
  Serial.write(0x20); // Run IPA 2 on interval 2.
}


void loop() {
  // put your main code here, to run repeatedly:

  int nID, nLuminance, nX, nY;
  int nRow0, nRow1, nRow2;

  if (Serial.available() > 3) // Make sure at least 4 bytes in the received buffer
  {
    nID = Serial.read(); // Get process ID.
    if (nID == 1) // Make sure the data is from IPA 1.
    {
      nLuminance = Serial.read();
      nX = Serial.read();
      nY = Serial.read();
    }
    else if (nID == 2) // Make sure the data is from IPA 2.
    {
      nRow2 = Serial.read();
      nRow1 = Serial.read();
      nRow0 = Serial.read();
    }
    else
    {
      Serial.flush(); // Flush received buffer.
    }
  }
}

Done compiling
Sketch uses 1684 bytes (5%) of program storage space. Maximum is 32256 bytes.
Global variables use 184 bytes (8%) of dynamic memory, leaving 1864 bytes for local
28 Arduino/Genuino Uno on COM28
```


Example 2 – The Assignment of IPAs to Intervals




- Each IPA only executes every 100 ms, thus the response time now slows down to 100 ms, however the up side is we get to run two different algorithms simultaneously.

Interpreting the Results of IPA 2

- When IPA 2 is activated:



Version 0.95 Dec 2019



Whenever the number of black pixels exceed a pre-determined threshold in a cell, an obstacle is deemed present. Thus, for this example, cells R0, M0 and R1 contains obstacle and the bits corresponding to these cells will be set to '1'. The following result packet will be transmitted via UART 1 from MVM V1.5C:

Byte 1 = 2 ID
 Byte 2 = 0b00000000 Row 2
 Byte 3 = 0b00000001 Row 1
 Byte 4 = 0b00000011 Row 0
 L M R

Compiling and Building Your Own Firmware for MVM V1.5C

Introduction 1

- The source codes for the sample firmware is a simplified version of the application pre-loaded into the MVM V1.5C micro-controller.
- The codes for IPA 1 is provided with the sample firmware and if the micro-controller is programmed with the sample firmware hex output, the micro-controller will run IPA 1 continuously at 20 fps upon power up.

Introduction 2

- Clone the MVM_V1_5C folder from https://github.com/fabiankung/MVM_V1_5C

The screenshot shows the GitHub repository 'MVM_V1_5C' with the following files and folders listed:

- MVM_Arduino_Example/Example1_SoftSerial
- MVM_Miscellaneous/Scilab
- MVM_Original_Hex_File_R0.53
- MVM_PC_Monitor_Software
- MVM_Sample_Firmware_R0.9
- LICENSE
- MVM_V1_5C_Quick_Start.pdf
- README.md


Annotations with red arrows point to specific files:

- A pink arrow points from the URL to the repository name.
- A yellow box labeled 'Original firmware in hex format' points to 'MVM_Original_Hex_File_R0.53'.
- A yellow box labeled 'PC Application and Source codes for MV Monitor software' points to 'MVM_PC_Monitor_Software'.
- A yellow box labeled 'Sample firmware in C for MVM V1.5C' points to 'MVM_Sample_Firmware_R0.9'.

- “MVM_Sample_Firmware” contains all the drivers files and IPA 1 routines. You can use this to build your own custom applications.
- “MVM_PC_Monitor_Software” contains the Visual Studio template to build up the Machine Vision Monitor software in Visual Basic .NET.


Setting Up An Atmel Studio Project 1

- Start a new project in Atmel Studio 7.




Setting Up An Atmel Studio Project 2

- Create a GCC C executable project.




Setting Up An Atmel Studio Project 3

- Select the correct device.




Setting Up An Atmel Studio Project 4

- A project with a default “main.c” file will be created.




Setting Up An Atmel Studio Project 5

- Now close Atmel Studio 7.
- Go to the project folder.




Setting Up An Atmel Studio Project 6

- Now reopen Atmel Studio 7. The new “main.c” file will be reflected window.




Setting Up An Atmel Studio Project 7

- Right click the folder “MVM” in the Solution Explorer, and select Add Existing Item...




Setting Up An Atmel Studio Project 8

- Add all the *.c and *.h files in the project folder to the project.




Setting Up An Atmel Studio Project 9

- Now you can build or compile the project.




Setting Up the Programming Tool – Atmel ICE

- Now you can load the firmware into the micro-controller with a suitable programmer. Here we are using Atmel ICE, but any programmer compatible with Atmel Studio 7 and support SWD (serial wire debug) mode is fine.



Flashing the Micro-Controller 1

- Connect the MVM to Atmel ICE. Power up the MVM and click this button to program the flash memory.
- See **Appendix** on the pin assignment on the 2x3 ways receptacle that comes with Atmel ICE.



Flashing the Micro-Controller 2

- Finally you need to setup the TCM (tightly coupled memory) size of Cortex M7 by setting the GPNVM (general purpose non-volatile memory) bits of SAMS70 as shown.

The screenshot shows the Atmel Studio interface with the 'Device Programming' window open. The 'GPNVM Bits' section is highlighted, showing the following configuration:

GPNVM Bit	Value
GPNVMBITS.BOOT_MODE	<input checked="" type="checkbox"/>
GPNVMBITS.TCM_CONFIGURATION	0x01

A red arrow points to the 'Program' button in the bottom right corner of the 'Device Programming' window.

The Heartbeat LED of the MVM V1.5C should start blinking once all the GPNVM bits are programmed.

Hit the 'Program' button once the parameters are properly setup.

Version 0.95 Dec 2019

Coding Your Own Routines

- The source files “**User_Task.c**” and “**User_Task.h**” contains the routines and declarations for **image processing task 1** that search for the brightest region in an image.
- Use this as the basis to add on your own routines. Do remember to use the state machine approach to code your tasks, and keep the total execution time for all tasks within 1 system ticks!
- For more information on the round-robin scheduler and basic structure of the C codes for ARM Cortex-M see <https://fkeng.blogspot.com/2016/02/atmel-arm-cortex-m4-microcontroller.html>




Compiling and Building the Machine Vision Monitor Software

Introduction

- The PC application (*.exe) to observe the image frames captured by the MVM and the corresponding source codes are also provided.
- If needed, you can rebuild the application using Visual Studio Community version and customize the software features.
- The following slides show how to setup the Visual Studio project from the source codes provided.


Setting Up Visual Studio Project 1

- In the folder “MVM_PC_Monitor_Software” look for the file MVMMon1.zip.
- Decompress the file into a suitable project folder.




Setting Up Visual Studio Project 2

- Open Visual Studio, and open the VB project (*.vbproj) as shown.




Setting Up Visual Studio Project 3

- Double-click the MyProject icon to bring up the project setting.



Setting Up Visual Studio Project 4


- Type in the Assembly Name and Root Namespace as shown.



Setting Up Visual Studio Project 5


- Now rebuild the project as shown and you should get a success message in the Output window.

Success
Message



Setting Up Visual Studio Project 6


- You can now run the application, view/edit the source code and the main window form.



APPENDIX


Programmer Connection, Examples and File Export

Connecting Atmel ICE to MVM V1.5C



Example 1 - Using MVM with Arduino Uno and SoftwareSerial Library

In this code we use SoftwareSerial port to communicate with MVM V1.5C, while the hardware serial is used in conjunction with Serial Terminal for debugging.



```
Example1_SoftSerial | Arduino 1.8.9
File Edit Sketch Tools Help

Example1_SoftSerial

SoftwareSerial mySerial(10, 11); // RX, TX

void setup() {
  // put your setup code here, to run once:
  Serial.begin(57600);
  mySerial.begin(57600);
  delay(500); // A 500 ms delay for the module to initiate
  mySerial.write(0x10); // Run IPA (image processing algorithm)
  mySerial.write(0x10); // Run IPA 1 on interval 2.
}

void loop() {
  // put your main code here, to run repeatedly:

  int nID;
  int nLuminance;
  int nX;
  int nY;

  if (mySerial.available() > 3)
  {
    nID = mySerial.read(); // Get IPA ID.
    if (nID == 1) // Make sure it is algorithm 1.
    {
      nLuminance = mySerial.read();
      nX = mySerial.read();
      nY = mySerial.read();
      Serial.print("Process ID = ");
      Serial.print(nID);
      Serial.println();
      Serial.print("X coordinate = ");
      Serial.print(nX);
      Serial.println();
      Serial.print("Y coordinate = ");
      Serial.print(nY);
      Serial.println();
    }
    else
    {
      mySerial.flush();
    }
  }
  delay(2); // A short 2 ms delay.
}


Done Saving.
Sketch uses 3874 bytes (12%) of program storage space. Maximum is 32768 bytes.
Global variables use 351 bytes (17%) of dynamic memory, leaving 1625 bytes free.

46 Arduino/Genuino Uno on COM15
```


Example 3 - Color Object Tracking with Arduino Uno

See sample code in GitHub repository


To 5V Power Supply (>1A output)
or Battery connected to 5V Voltage Regulator




Example 3 - Mechanical Setup



Example 4 - Autonomous Navigation with Arduino Uno Based Robocar



Example 4 - Wiring Information of Robocar




Arduino Uno R3

- Pin 2, 4 – Left DC motor direction control.
- Pin 7, 8 – Right DC motor direction control.
- Pin 5 – Left DC motor speed control.
- Pin 6 – Right DC motor speed control.
- Pin 10 – RX, to MVM TX pin.
- Pin 11 – TX, to MVM RX pin via 100 Ω resistor.
- Optional: Pin 3 for azimuth servo motor control and Pin 12 for elevation servo motor control.

Saving the Image Frame onto Computer Harddisk and Retriving the Image using Scilab or MATLAB software

- As mentioned in slide #13, one can save the image displayed in the Machine Vision Monitor software onto hard disk.
- The image file is saved as a binary file containing 2D array of luminance pixels.
- Scilab or MATLAB software to read the file and display the image. This is useful when one is developing a new algorithm.

1. Close the COM port to stop streaming image



2. Save the current bitmap in display onto hard disk

Continued...

- The Scilab script to read the saved image file is also provided in the MVM_V1_5C folder. The script listing is shown below.

Make sure the path declaration matches your file path in the hard disk

```
1 // Author:.....: Fabian-Rung
2 // Last modified:.....: 29.Oct.2016
3 // Purpose:.....: Basic code to load a 8-bit grayscale image from file
4
5 clear;
6 ImageWidth = 160; .....: // Set the size of the image. QVGA.
7 ImageHeight = 120;
8 Hgraf = scf(); .....: // Get the handle to current graphic window.
9 path = cd('C:\tmp'); .....: // Path for the image file.
10 Hfile = mopen('testimage.txt', 'rb'); .....: // Open a text file for reading.
11 .....: // (don't skip 0x0D, newline character)
12 M = zeros(ImageHeight+1, ImageWidth+1); .....: // Matrix to hold the gray-scale image data
13 Mt = zeros(ImageWidth+1, ImageHeight+1); .....: // Another matrix also to hold the gray-scale image data.
14 .....: // 't' indicate transpose.
15 for i=1:ImageHeight-1 .....: // ImageHeight-1 due to the last line is not
16 .....: // exported from the camera monitor software
17 for j=1:ImageWidth
18 M(i,j) = mget(1,'c',Hfile); .....: // Read 1 pixel data, convert to double.
19 end
20 mget(1,'c',Hfile); .....: // Read the newline/carriage return character.
21 end
22
23 for i=1:ImageHeight-1 .....: // Transpose and flip the image so that
24 for j=1:ImageWidth .....: // it appear at the correct orientation.
25 Mt(j, ImageHeight-i) = M(i,j) .....: // The original format of M[j] is:
26 end .....: // -----> Column
27 end .....: // -1
28 .....: // -1
29 .....: // -1
30 .....: // V
31 .....: // Row
32
33 mclose(Hfile); .....: // Release file handle.
34
35 //Hgraf.color_map = graycolormap(127); .....: // Set current graphic window color map
36 Hgraf.color_map = graycolormap(255); .....: // to gray-scale, 127 or 255 levels.
37 row = 1:ImageWidth + 1;
38 col = 1:ImageHeight + 1;
39 grayplot(row,col,Mt); .....: // Plot the transpose and flip image.
40
```

Graphic window number 0

